

Wildlife Globe EDU-37149

IMPORTANT SAFETY INSTRUCTIONS

CAUTION: THIS GLOBE HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). TO PREVENT ELECTRIC SHOCK.. MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

SAVE THESE INSTRUCTIONS



Note

- Indoor use only.
- **WARNING:** To avoid any potential hazards, if the power cord for this product is damaged it may only be replaced by the manufacturers, their service representatives, or by a comparable qualified technician.

Instructions for changing the lamp

Instructions for replacing the lamp

1. Take the plug out of the socket.
2. Bend the meridian (2) of the globe slightly upwards and so draw the securing pin out of the North Pole opening in the globe (1).
3. Now push the globe sphere (1) to the side. Push against the globe sphere from below and lift it out of its mounting.
4. Now you can see the lamp. Change it in the usual way, replacing it with a bulb of E12 shape, 120V and max. 25 Watt.
5. Place the globe sphere back in the frame.
6. Bend the globe meridian (2) somewhat upwards again, and push the remaining element back onto the north pole of the globe sphere.